

5225.0400 BASIC LICENSE REQUIREMENT AND DUTY.

No person shall have charge of or operate any boiler or boiler plant who does not possess a license of the class required to operate the boiler or boiler plant.

It is the duty of the owner of a boiler or boiler plant and the chief engineer and all boiler inspectors, including those employed by insurance companies, to promptly report to the chief boiler inspector, any boiler or boiler plant in which the engineer has no license or a license of a lower class than that required by law for the horsepower of the boiler or boiler plant.

Statutory Authority: *MS s 175.171; 183.42; 183.44; 183.465; 183.466; 183.501; 183.54; 326B.958; 326B.964; 326B.966; 326B.972; 326B.982*

History: *19 SR 591; L 2007 c 140 art 9 s 27; art 13 s 4*

Published Electronically: *February 19, 2009*